

# **User Manual**

# **Solar Power Converter SPC III**



# **Table Of Contents**

ABOUT THIS MANUAL	
Purpose	2
Scope	2
SAFETY INSTRUCTIONS	
INTRODUCTION	3
Features	
Basic System ArchitectureProduct Overview	
INSTALLATION	
Unpacking and Inspection	
Preparation	
Mounting the Unit	
Battery Connection	
AC Input/Output Connection	
PV Connection	
Final Assembly	
Remote Display Panel Installation	
Communication Options	
Dry Contact Signal	13
BMS Communication	13
OPERATION	14
Power ON/OFF	14
Operation and Display Panel	14
LCD Display Icons	15
LCD Setting	17
Display Setting	30
Operating Mode Description	35
Battery Equalization Description	
Fault Reference Code	
Warning Indicator	39
SPECIFICATIONS	40
Table 1 Line Mode Specifications	40
Table 2 Inverter Mode Specifications	41
Table 3 Charge Mode Specifications	
Table 4 General Specifications	42
TROUBLE SHOOTING	43
Appendix A: Approximate Back-up Time Table	44
Appendix B: BMS Communication Installation	45

### **ABOUT THIS MANUAL**

### **Purpose**

This manual describes the assembly, installation, operation and troubleshooting of this unit. Please read this manual carefully before installations and operations. Keep this manual for future reference.

### **Scope**

This manual provides safety and installation guidelines as well as information on tools and wiring.

### **SAFETY INSTRUCTIONS**



WARNING: All safety instructions in this document must be read, understood and followed. Failure to follow these instructions will result in death or serious injury.

- 1. Before using the unit, read all instructions and cautionary markings on the unit, the batteries and all appropriate sections of this manual.
- 2. **CAUTION** --To reduce risk of injury, charge only deep-cycle lead acid type rechargeable batteries. Other types of batteries may burst, causing personal injury and damage.
- 3. Do not disassemble the unit. Take it to a qualified service center when service or repair is required. Incorrect re-assembly may result in a risk of electric shock or fire.
- 4. To reduce risk of electric shock, disconnect all wirings before attempting any maintenance or cleaning. Turning off the unit will not reduce this risk.
- 5. **CAUTION** Only qualified personnel can install this device with battery.
- 6. **NEVER** charge a frozen battery.
- 7. For optimum operation of this inverter/charger, please follow required spec to select appropriate cable size. It's very important to correctly operate this inverter/charger.
- 8. Be very cautious when working with metal tools on or around batteries. A potential risk exists to drop a tool to spark or short circuit batteries or other electrical parts and could cause an explosion.
- 9. Please strictly follow installation procedure when you want to disconnect AC or DC terminals. Please refer to INSTALLATION section of this manual for the details.
- 10. One piece of 150A fuse is provided as over-current protection for the battery supply.
- 11. GROUNDING INSTRUCTIONS -This inverter/charger should be connected to a permanent grounded wiring system. Be sure to comply with local requirements and regulation to install this inverter.
- 12. NEVER cause AC output and DC input short circuited. Do NOT connect to the mains when DC input short circuits.
- 13. **Warning!!** Only qualified service persons are able to service this device. If errors still persist after following troubleshooting table, please send this inverter/charger back to local dealer or service center for maintenance.
- 14. WARNING: Because this inverter is non-isolated, only three types of PV modules are acceptable: single crystalline, poly crystalline with class A-rated and CIGS modules. To avoid any malfunction, do not connect any PV modules with possible current leakage to the inverter. For example, grounded PV modules will cause current leakage to the inverter. When using CIGS modules, please be sure NO grounding.
- 15. **CAUTION:** It's requested to use PV junction box with surge protection. Otherwise, it will cause damage on inverter when lightning occurs on PV modules.

#### **INTRODUCTION**

This is a multi-function inverter, combining functions of inverter, solar charger and battery charger to offer uninterruptible power support in a single package. The comprehensive LCD display offers user-configurable and easy-accessible button operations such as battery charging current, AC or solar charging priority, and acceptable input voltage based on different applications.

#### **Features**

- Pure sine wave inverter
- Configurable input voltage ranges for home appliances and personal computers via LCD control panel
- Configurable battery charging current based on applications via LCD control panel
- Configurable AC/Solar Charger priority via LCD control panel
- Compatible to utility mains or generator power
- Auto restart while AC is recovering
- Overload / Over temperature / short circuit protection
- Smart battery charger design for optimized battery performance
- Cold start function
- · Removable LCD control module
- Multiple communication ports for BMS (RS485, CAN-BUS, RS232)
- Built-in Bluetooth for mobile monitoring (Requires App), OTG USB function, dusk filters
- Configurable AC/PV Output usage timer and prioritization

### **Basic System Architecture**

The following illustration shows basic application for this unit. It also required the following devices to have a complete running system:

- Generator or Utility mains.
- · PV modules

Consult with your system integrator for other possible system architectures depending on your requirements.

This inverter can power various appliances in home or office environment, including motor-type appliances such as tube light, fan, refrigerator and air conditioners.





Figure 1 Hybrid Power System

### **Product Overview**



- 1. LCD display
- 2. Status indicator
- 3. Charging indicator
- 4. Fault indicator
- 5. Function buttons
- 6. Power on/off switch
- 7. AC input
- 8. AC output
- 9. PV input
- 10. Battery input
- 11. Circuit breaker
- 12. Remote LCD panel communication port
- 13. Dry contact
- 14. USB communication port
- 15. BMS communication port: CAN and RS232 or RS485
- 16. RS-232 communication port
- 17. Output source indicators (refer to OPERATION/Operation and Display Panel section for details) and USB function setting reminder (refer to OPERATION/Function Setting for the details)

### **INSTALLATION**


### **Unpacking and Inspection**

Before installation, please inspect the content. Be sure that nothing inside the package is damaged. You should have received the following items inside the package:

- Inverter x 1
- User manual x 1
- RS232 Communication cable x 1
- · Software CD x 1
- DC Fuse x 1

### **Preparation**


Before connecting all wirings, please take off the bottom cover by removing two screws as shown below. Detach the cables from the cover.



### **Mounting the Unit**

Consider the followings before selecting your placements:


- Do not mount the inverter on flammable construction materials.
- Mount on a solid surface
- Install the inverter at eye level in order to allow easy LCD display readout.
- For proper air circulation and heat dissipation, allow a clearance of approx. 20 cm to the side and approx. 50 cm above and below the unit.
- The ambient temperature should be between 0°C and 55°C to ensure optimal operation.
- The recommended orientation is to adhered to the wall vertically.
   Be sure to keep other objects and surfaces as shown in the diagram to guarantee sufficient heat dissipation and to have enough space for wirings.



 $\triangle$ 

SUITABLE FOR MOUNTING ON CONCRETE OR OTHER NON-COMBUSTIBLE SURFACE ONLY.

Mounting the unit by screwing the three screws as shown below. It's recommended to use M4 or M5 screws.




### **Battery Connection**

**CAUTION:** For safety operation and regulation compliance, it's requested to install a separate DC over-current protector or disconnection device between battery and the inverter. It may not be necessary to have a disconnection device in some applications, however, it's still recommended to have over-current protection installed. Please refer to typical amperage as required.

**WARNING!** All wiring must be performed by a qualified electrical technician. **WARNING!** It's very important for system safety and efficient operation to use appropriate cables for battery connection. To reduce risk of injury, please use the proper recommended cable in the table below.

### Ring terminal:






### **Recommended battery cable size:**


Model	Typical	Wire Size	Cable	Ring Te	erminal	Torque
	Amperage		mm²	Dimen	sions	Value
				D (mm)	L (mm)	
1.5KW	71A	1*6AWG	14	N/	<b>′</b> A	2 Nm
3KW	142A	1*2AWG	38	8.4	39.2	□ Noo
5KW	118A	1*2AWG	38	8.4	39.2	5 Nm

Please take the following steps to implement battery connection:

- 1. Assemble battery ring terminal based on recommended battery cable and terminal size. This step only applied to 3KW/5KW models.
- 2. Connect all battery packs as required. It is recommend to connect minimum of 100Ah capacity battery for 1.5KW/3KW model and 200Ah capacity battery for 5KW model.



3. For the 1.5KW model, remove the insulation sleeve for about 18mm for positive and negative wires. Connect the two wires to the proper screw terminal on the unit. For 3KW/5KW models, apply ring terminals to your battery wires and secure it to the battery terminal block with the bolts properly tightened. Refer to battery cable size for torque value. Make sure polarity at both the battery and the inverter is correctly connected and ring terminals are secured to the battery terminals.



 $\triangle$ 

**WARNING: Shock Hazard** 

Installation must be performed with care due to high battery voltage in series.

Æ

**CAUTION!!** Do not place anything between inverter terminals and the ring terminals. Otherwise, overheating may occur.

**CAUTION!!** Do not apply anti-oxidant substance on the terminals before terminals are securely tightened.

**CAUTION!!** Before making final DC connection or closing DC breaker/disconnector, be sure that the positive (+) must be connected to positive (+) and negative (-) connected to negative (-).

### **AC Input/Output Connection**

**CAUTION!!** Before connecting to AC input power source, please install a **separate** AC breaker between the inverter and the AC input power source. This will ensure that the inverter can be safely disconnected during maintenance and fully protected from over-current. The recommended spec of AC breaker is 16A for 1.5KW and 32A for 3KW and 50A for 5KW.

**CAUTION!!** There are two power terminal blocks with "IN" (Input) and "OUT" (Output) markings. DO NOT mistakenly connect to the wrong connectors.

**WARNING!** All wiring must be performed by a qualified personnel.


**WARNING!** It's very important for system safety and efficient operation to use appropriate cable size for AC input connection. To reduce risk of injury, please use the proper recommended cable size as below.

#### Suggested cable requirement for AC wires

Model	Gauge	Cable (mm²)	Torque Value
1.5KW	14 AWG	2.5	1.2 Nm
3KW	12 AWG	4	1.2 Nm
5KW	10 AWG	6	1.2 Nm

Please follow these steps to implement AC input/output connection:

- 1. Before making AC input/output connection, be sure to enable DC protector or disconnector first.
- 2. Remove insulation sleeves for about 10mm for the five screw terminals.
- 3. Insert AC input wires according to polarities indicated on terminal block and tighten the terminal screws. Be sure to connect the grounding wire ( ) first.
  - ⊕→Ground (yellow-green)
  - L→LINE (brown or black)
  - N→Neutral (blue)






#### **WARNING:**

Be sure that the AC power source is disconnected before attempting wire connections.

- 4. Insert AC output wires according to polarities indicated on terminal block and tighten terminal screws. Be sure to connect the grounding wire ( ) first.
  - **Ground** (yellow-green)
  - L→LINE (brown or black)
  - N→Neutral (blue)
- 5. Make sure the wires are securely connected.



**CAUTION:** Appliances such as air conditioner required at least 2~3 minutes to spool up because it needs to have enough time to balance refrigerant gas inside of circuits. If a power shortage occurs and recovers in a short period of time, it may cause damage to your connected appliances. To prevent this from happening, please check with manufacturer of air conditioner if it has time-delay function before installation. Otherwise, this inverter will trigger overload fault and cut off output to protect your appliance but sometimes it may still causes damage to the air conditioner.

#### **PV Connection**

**CAUTION:** Before connecting to PV modules, please install a **separately** DC circuit breaker between the inverter and PV modules.

**WARNING!** It's very important for system safety and efficient operation to use appropriate cable for PV module connection. To reduce risk of injury, please use the proper recommended cable size shown below.

Model	Wire Size	Cable (mm²)	Torque value (max)
1.5KW	1 x 14AWG	2.5	1.2 Nm
3KW/5KW	1 x 12AWG	4	1.2 Nm

**WARNING:** Because this inverter is non-isolated, are accepted: single crystalline, poly crystalline with class A-rated and CIGS modules. To avoid any malfunctions, do not connect any PV modules with possible current leakage to the inverter. For example, grounded PV modules will cause current leakage to the inverter. When using CIGS modules, please be sure NO grounding connection.

**CAUTION:** It's requested to use PV junction box with surge protection. Otherwise, it will cause damage on inverter when lightning occurs on PV modules.

#### **PV Module Selection:**

When selecting proper PV modules, please be sure to consider the following parameters:

 Open circuit Voltage (Voc) of PV modules not to exceeds maximum PV array open circuit voltage of the inverter.

2. Open circuit Voltage (Voc) of PV modules should be higher than the start-up voltage.

INVERTER MODEL	1.5KW	3KW	5KW
Max. PV Array Power	2000W	4000W 5000V	
Max. PV Array Open Circuit Voltage	400Vdc	500Vdc	
PV Array MPPT Voltage Range	120Vdc~380Vdc	120Vdc~450Vdc	
Start-up Voltage	150Vdc +/- 10Vdc		

Take the 250Wp PV module as an example. After considering above two parameters, the recommended module configurations are listed in the table below.

Solar Panel Spec. (reference) - 250Wp	SOLAR INPUT  (For 1.5KW, Min in serial: 5 pcs, max. in serial: 8 pcs. For 3KW/5KW, Min in serial: 6 pcs, max. in serial: 12 pcs.)	Q'ty of panels	Total input power
- Vmp: 30.1Vdc - Imp: 8.3A	6 pcs in serial	6 pcs	1500W
- Voc: 37.7Vdc	8 pcs in serial	8 pcs	2000W
- Voc. 37.7 vdc - Isc: 8.4A	12 pcs in serial	12 pcs	3000W
- Cells: 60	8 pieces in serial and 2 sets in parallel	16 pcs	4000W
- Celis. 60	10 pieces in serial and 2 sets in parallel (only for 5KVA model)	20 pcs	5000W




### **PV Module Wire Connection**

Please take the following to implement PV module connection:


- 1. Remove insulation sleeve for about 7 mm on your positive and negative wires.
- 2. We recommend using bootlace ferrules on the wires for optimal performance.
- 3. Check polarities of wire connections from PV modules to PV input screw terminals. Connect your wires as illustrated below.

Recommended tool: 4mm blade screwdriver



### **Final Assembly**


After connecting all wirings, replace the bottom cover as shown below.




### **Remote Display Panel Installation**

The LCD module can be removable and installed in a remote location with an optional communication cable. Please take the follow steps to implement this remote panel installation.

**Step 1.** Remove the screw on the bottom of LCD panel and pull down the module from the case. Detach the cable from the remote communication port. Be sure to replace the retention plate back to the inverter.




**Step 2.** Prepare your mounting holes in the marked locations as shown in the illustration below. The LCD module then can be securely mounted to your desired location.



**Note:** Wall installation should be implemented with the proper screws to the right.



**Step 3.** Connect LCD module to the inverter with an optional RJ45 communication cable as shown below.



### **Communication Options**

#### **Serial Connection**

Please use the supplied serial cable to connect between the inverter and your PC. Install the monitoring software from the bundled CD and follow the on-screen instructions to complete your installation. For detailed software operation, refer to the software user manual on the bundled CD.

#### **Bluetooth Connection**

This unit is equipped with a Bluetooth transmitter. Download "WatchPower" APP from Google Play or Google Store. Once the APP is download, you may connect "WatchPower" APP to your inverter with the password "123456". The communication distance is roughly  $6 \sim 7$  meters.



# **Dry Contact Signal**

There is one dry contact (3A/250VAC) available on the rear panel. It could be used to deliver signal to external device when battery voltage reaches warning level.

Unit Status	Condition			Condition		Dry contact	port: NC C NO
				NC & C	NO & C		
Power Off	Unit is off and	no output is pow	vered.	Close	Open		
	Output is powered	Program 01 set as USB	Battery voltage < Low DC warning voltage	Open	Close		
Power On	from Battery power or Solar energy.	(utility first)	Battery voltage > Setting value in Program 13 or battery charging reaches floating stage	Close	Open		
1 ower on		Program 01 is set as SBU	Battery voltage < Setting value in Program 12	Open	Close		
		(SBU priority)	Battery voltage > Setting value in Program 13 or battery charging reaches floating stage	Close	Open		

### **BMS Communication**

It is recommended to purchase a special communication cable if you are connecting to Lithium-Ion battery banks. Please refer to Appendix B- BMS Communication Installation for details.

### **OPERATION**


### **Power ON/OFF**



Once the unit has been properly installed and the batteries are connected well, simply press On/Off switch (located on the LCD module) to turn on the unit.

### **Operation and Display Panel**

The operation and the LCD module, shown in the chart below, includes six indicators, six function keys, on/off switch and a LCD display, indicating the operating status and input/output power information.




#### **Indicators**

LED In	dicator	Color	Solid/Flashing	Messages
Settin	g LED 1	Green	Solid On	Output powered by utility
Settin	g LED 2	Green	Solid On	Output powered by PV
Settin	g LED 3	Green	Solid On	Output powered by battery
	→ AC → INV		Solid On	Output is available in line mode
			Flashing	Output is powered by battery in battery mode
Status	× ••• •		Solid On	Battery is fully charged
indicators	-X- CHG	Green	Flashing	Battery is charging.
EAULT		Dod	Solid On	Fault mode
FAULT	Red	Flashing	Warning mode	

# **Function Keys**

Fi	unction Key	Description
₩/ <b>७</b>	ESC	Exit the setting
₩/U	USB function setting	Select USB OTG functions
<b>1</b>	Timer setting for the	Cotup the times for prioritizing the output course
7	Output source priority	Setup the timer for prioritizing the output source
<b>ביי</b> עיערי	Timer setting for the	Setup the timer for prioritizing the charger source
<del>]</del> \$	Charger source priority	Setup the timer for phontizing the charger source
<b>A</b>	Up	To last selection
~	Down	To next selection
<b>←</b>	Enter	To confirm/enter the selection in setting mode

# **LCD Display Icons**



Icon	Function description				
Input Source Information					
AC	Indicates the AC input.				
PV	Indicates the PV input				
INPUT BATH AS IEV	Indicate input voltage, input frequency, PV voltage, charger current,				
888	charger power, battery voltage.				
Configuration Program and Fa	ault Information				
888	Indicates the setting programs.				
888	Indicates the warning and fault codes.  Warning: Bahing with warning code.  Fault: Balighting with fault code				
Output Information					
OUTPUTBATTIEMP I With	Indicate output voltage, output frequency, load percent, load in VA,				
	load in Watt and discharging current.				
Battery Information					
BATT	Indicates battery level by 0-24%, 25-49%, 50-74% and 75-100% in battery mode and charging status in line mode.				
When battery is charging, it will present battery charging status.					

Status	Battery voltag	e	LCD Display	
	<2V/cell		4 bars will fla	
Constant	2 ~ 2.083V/ce	ell	bars will flash	
Current mode / Constant	2.083 ~ 2.167	7V/cell	Bottom two b bars will flash	ars will be on and the other two in turns.
Voltage mode	> 2.167 V/cel	I	Bottom three will flash.	bars will be on and the top bar
Floating mode. E	Batteries are ful	ly charged.	4 bars will be	on.
n battery mode,	it will present b	attery capacity.	•	
Load Percentage		Battery Voltage		LCD Display
		< 1.85V/cell		LOWBATT
		1.85V/cell ~ 1.933V/cell		BATT
Load >50%		1.933V/cell ~ 2.017V/cell		BATT
		> 2.017V/cell		BATT A S
		< 1.892V/cell		LOWBATT
		1.892V/cell ~ 1.975V/cell		BATT
Load < 50%		1.975V/cell ~ 2.058V/cell		BATT ===
		> 2.058V/cell		BATT
oad Informatio	on			27111
	*	Indicates overlo	oad.	
LOAD		Indicates the lo	ad level by 0-24	1%, 25-49%, 50-74% and 75-10
		0%	~24%	25%~49%
		LOAD		LOAD

LOAD	Thurcates the load level by 0-2+70, 23-4970, 30-7470 and 73-1				
	0%~24%	25%~49%			
	LOAD	LOAD			
	50%~74%	75%~100%			
	LOAD	LOAD			
<b>Mode Operation Information</b>					
igorphi	Indicates unit connects to the ma	ins.			
MPPI	Indicates unit connects to the PV panel.				
BYPASS	Indicates load is supplied by utility power.				
<b></b>	Indicates the utility charger circuit is working.				
<b>F</b>	Indicates the solar charger circuit is working.				
<b></b>	Indicates the DC/AC inverter circuit is working.				
	Indicates unit alarm is disabled.				
*	Indicates Bluetooth is ready to connect.				
USBE	Indicates USB disk is connected.				
	Indicates timer setting or time display				

# **LCD Setting**

# **General Setting**

After pressing and holding "\" button for 3 seconds, the unit will enter the Setup Mode. Press " \" or "\" button to select setting programs. Press "\" button to confirm you selection or "\" button to exit.

### **Setting Programs:**

Program	Description	Selectable option	
00	Exit setting mode	Escape 💮 💮	
		850	
		Utility first (default)	Utility will provide power to the loads as first priority.  Solar and battery energy will provide power to the loads only when utility power is not available.
01	Output source priority: To configure load power source priority	Solar first	Solar energy provides power to the loads as first priority.  If solar energy is not sufficient to power all connected loads, Utility energy will supply power to the loads at the same time.
		SBU priority	Solar energy provides power to the loads as first priority.  If solar energy is not sufficient to power all connected loads, battery energy will supply power to the loads at the same time.  Utility provides power to the loads only when battery voltage drops to sither love level warning voltage are
	Maximum charging current:	10A	either low-level warning voltage or the setting point in program 12. 20A
02	To configure total charging current for solar and utility chargers. (Max. charging current =	<u>0</u> 5 •	02 👁
	utility charging current + solar charging current)	10^	50·

		T	T
		02 <b>©</b>	40A 02 <b>®</b>
		30^	40.
		02 <b>®</b>	60A (default)
		S0 <sup>*</sup>	60 <sub>^</sub>
		70A (only for 3KW/5KW)	80A (only for 3KW/5KW)
		٦0٠	80.
		Appliances (default)	If selected, acceptable AC input voltage range will be within 90-280VAC.
03	AC input voltage range	APL	
		UPS <b>◎</b>	If selected, acceptable AC input voltage range will be within 170-280VAC.
		UPS	
		AGM (default)	Flooded
05	Battery type	86-	FLd
		User-Defined	If "User-Defined" is selected, battery charge voltage and low DC cut-off voltage can be set up in program 26, 27 and 29.
		USE	
05	Battery type	Pylontech battery (only for 5KW)	If selected, programs of 02, 26, 27 and 29 will be automatically set up. No need for further setting.
		PYL	

		WECO battery (only for 5kW)	If selected, programs of 02, 12, 26, 27 and 29 will be auto-configured per battery supplier recommended. No need for further adjustment.
		Soltaro battery (only for 5kW)	If selected, programs of 02, 26, 27 and 29 will be automatically set up. No need for further setting.
		50L	
05	Battery type	BAK battery (only for 5kW)	If selected, programs of 02, 26, 27 and 29 will be automatically set up. No need for further setting.
	, ,,	68F	
		LIb-protocol compatible battery (only for 5kW)	Select "LIb" if using Lithium battery compatible to Lib protocol. If selected, programs of 02, 26, 27 and 29 will be automatically set up. No need for further setting.
		UЬ	
		3 <sup>rd</sup> party Lithium battery (only for 5kW)	If selected, programs of 02, 26, 27 and 29 will be automatically set up. No need for further setting. Please contact the battery supplier for installation procedure.
		LIC	

		D +     -   -   -   -	Dontont cookle
		Restart disable (default)	Restart enable
		86 <b>©</b>	06 <b>©</b>
06	Auto restart when overload		
	occurs		
		LHd	L+E
		Restart disable (default)	Restart enable
	Auto restart when over	<b>®</b>	[] ↑ 🚳
07	temperature occurs		
		논논성	<b>Ł</b> +E
		50Hz (default)	60Hz
		09 🛮	89 🗞
09	Output frequency		
		50,,	60 <sub>**</sub>
		220V	230V (default)
		18 💩	W
10	Output voltage	220 <sup>,</sup>	230 <sup>*</sup>
10	Output voltage	240V	
		<b>5</b>	
		240 <sub>°</sub>	
		2A	10A
		🚳	@
		1 11 1	131.1
		UE1	UEI
		J.	I∏ ^
	Maximum utility charging	204	10
	current	20A !! <b>③</b>	30A (default)
	Note: If setting value in	i i 🐷	i i 🐷
11	program 02 is smaller than	UEI	UEI
	that in program in 11, the inverter will apply charging	Value Parist	
	current from program 02 for	20,	]
	utility charger.	40A	50A (only for 3KW/5KW)
		🚳	] [ 🐵
		lUE!	UE
		110	
		``i <u>`</u> i`	<b>``J</b> `L'^

		60A (only for 3KW/5KW)	
		UEI	
		60^	
		Available options in 1.5KW/3k	(W model:
		22.0V	12 <b>©</b>
		2 BATT V	BAIT V
		23.0V (default)	23.5V 12 <b>®</b>
		24.0V	24.5V
12	Setting voltage point back to utility source when selecting "SBU" (SBU	12 🚳	12 🐵
	priority) in program 01.	BATT V	245 <sub>v</sub>
		25.0V	25.5V 12
		25□v	BATT
		Available options in 5KW mod  44V	el: 45V <b>6</b>
		BATT	BATT L. C. v
		ŲŲ.	<u>'-</u> ', '-, ∨

		46V (default)	47V
	Setting voltage point back	48V	BATT
12	to utility source when selecting "SBU" (SBU priority) in program 01.	50V 12 <b>⊗</b>	BATT S1V ↓
		Available options in 1.5KW/3I	BATT  v
		Battery fully charged	24V
		F LIL v	2 HATT
		24.5V	25V
13	Setting voltage point back to battery mode when selecting "SBU" (SBU	25.5V	26V
	priority) in program 01.	13 👁	3 ●
		26.5V _	27V (default)
		13 👁	} ●
		26.5°	

		27.5V	28V
		28.5V	280v 29V
		Available options in 5KW mod Battery fully charged	el:  48V
13	Setting voltage point back to battery mode when selecting "SBU" (SBU	49V	50V
	priority) in program 01.	51V	52V
		53V 	54V (default)
		55V	56V
		SSV	SE,

	1	T	
13	Setting voltage point back to battery mode when selecting "SBU" (SBU priority) in program 01.	57V   <b>                                   </b>	58V 13 <b>©</b> 58v
		If this inverter/charger is wor	king in Line, Standby or Fault mode,
		charger source can be progra	mmed as below:
		Solar first	Solar energy will charge battery as
			first priority.
			Utility will charge battery only when solar energy is not available.
			When sold energy is not available.
		CS0	
		Solar and Utility (default)	Solar energy and utility will charge
		16 🚳	battery at the same time.
16	Charger source priority:  To configure charger source		
10	priority		
	process,	SAU	
		Only Solar	Solar energy will be the only
		16 🚳	charger source no matter utility is
		_	available or not.
		050	
			king in Battery mode, only solar
			plar energy will charge battery if it's
		available and sufficient.  Alarm on (default)	Alarm off
		Auditi on (acidale)	Auditi on
18	Alarm control		
		. ==	. ==
		60N	60F
		Return to default display	If selected, no matter how users
		screen (default)	switch display screen, it will
		IO @	automatically return to default
19	Auto return to default display screen	ים בי	display screen (Input voltage /output voltage) after no button is
	,		pressed for 1 minute.
		ESP	

		Stay at latest scree	en	•	the display screen will
		9 <b>©</b>		stay at lates switches.	t screen user finally
		F65			
		Backlight on (defau	ılt)	Backlight off	
		50 💩		20	<b>®</b>
20	Backlight control				
		LON		LOF	
		Alarm on (default)		Alarm off	
	Beeps while primary source	22 <b>®</b>		22	<b>(*)</b>
22	is interrupted				
		RON		80F	
		Bypass disable (de	fault)	Bypass enab	le
	Overload bypass: When enabled, the unit will	23 👁		53	<b>⊗</b>
23	transfer to line mode if overload occurs in battery				
	mode.	P39		6 <b>9</b> 8	
		Record enable (def	ault)	Record disab	ole
		25 🚳		25	<b>⊗</b>
25	Record Fault code	5			
		FEN		FdS	
		1.5KW/3KW defaul 28.2V	t setting:	5KW default	setting: 56.4V
				- 26	<b>®</b>
				۲۰	
26	Bulk charging voltage	E L		SE4v	
	(C.V voltage)			ایار	
			_	_	s program can be set or 1.5KW/3KW model
		and 48.0V to 61.0\			nent of each click is
		0.1V.			

	T	T		
		1.5KW/3KW default setting	: 5KW default setting: 54.0V	
		27.0V	<b>⊃</b> 7 ፟፟	
		P		
27		F. C	⊆ U∏ <sub>v</sub>	
27	Floating charging voltage		2.00	
			n program 5, this program can be set	
		, ,	25.0V to 31.5V for 1.5KW/3KW model W model. Increment of each click is	
		0.1V.	The chief of cach check is	
	Low DC cut-off voltage:	1.5KW/3KW default setting	: 5KW default setting: 42.0V	
	<ul> <li>If battery power is only power source available,</li> </ul>	21.0V		
	inverter will shut down.	29 🚳	29 🚳	
	<ul> <li>If PV energy and battery power are available,</li> </ul>	CUO	COO	
	inverter will charge	BATT	BATT	
29	battery without AC output.		'   -   -   -   -   -   -   -   -   -	
	<ul> <li>If PV energy, battery</li> </ul>	If self-defined is selected in program 5, this program can be set		
	power and utility are all available, inverter will transfer to line mode and provide output power to loads.	up. Setting range is from 21.0V to 24.0V for 1.5KW/3KW model		
		and 42.0V to 48.0V for 5KW model. Increment of each click is		
		0.1V. Low DC cut-off voltage will be fixed to setting value no matter what percentage of load is connected.		
	power to loads.	Battery equalization	Battery equalization disable	
		buccery equalization	(default)	
		30 🚳	1 3	
		50	50	
30	Battery equalization			
		880	E4S	
			ed" is selected in program 05, this	
		program can be set up.		
		1.5KW/3KW default setting	: 5KW default setting: 58.4V	
		29.2V	∃ ¦ 🏶	
		∃¦ 🚳	CLI	
31	Battery equalization voltage	Çυ	BATT	
31	Dattery equalization voltage	BATT	S84 <sub>"</sub>	
		c'5 <u>.c</u> v		
		Setting range is from 25.0\	to 31.5V for 1.5KW/3KW model and	
			odel. Increment of each click is 0.1V.	
		60min (default)	Setting range is from 5min to 900min.	
		<del>                                    </del>	Increment of each click is 5min.	
33	Battery equalized time			
		60		

		120min (dofault)	Cotting range is from Emin to 000 min
34	Battery equalized timeout	120min (default)	Setting range is from 5min to 900 min.  Increment of each click is 5 min.
		120	
35	Equalization interval	30days (default)	Setting range is from 0 to 90 days.  Increment of each click is 1 day
		304	
		Enable   36	Disable (default)
36	Equalization activated	REN	885
	immediately	be set up. If "Enable" is se battery equalization immed	nabled in program 30, this program can lected in this program, it's to activate diately and LCD main page will shows ted, it will cancel equalization function
		until next activated equal <u>iz</u> a	ation time arrives based on program 35 " will not be shown in LCD main page.
37	Reset all stored data for PV generated power and output load energy	Not reset(Default)	Reset   37
	, ,	UFF	FSE .
		Not reset(Default)	Reset
93	Erase all data log	93 🛮	93 👁
		UFF	FSE
		3 minutes	5 minutes 94 @
94	Data log recorded interval  *The maximum data log number is 1440. If it's over	3	S
9 <del>1</del>	1440, it will re-write the first log.	10 minutes (default)	20 minutes
		10	20

	T	T	T
		30 minutes	60 minutes
		Q <b>4 ®</b>	익낙 🚳
		]	]
		20	CO.
		30	168
		For minute setting, the range	is from 0 to 59.
		Q <b>Q</b> 🗞	
		77 -0	
95	Time setting – Minute	_! 0	
		ni ii	
		$\cap$	
		For hour setting, the range is	from 0 to 23.
		- 무도 ®®	
96	Time setting – Hour		
90	Time setting – Hour	HUU	
		11	
		For day setting, the range is f	from 1 to 31.
		_, , ,	
97	Time setting– Day	1987	
		0.75	
		!	
		For month setting, the range	is from 1 to 12.
			10 110111 2 121
		76 ~	
98	Time setting- Month	00	
		nuii	
		1	
		İ	
		For year setting, the range is	from 17 to 99.
		- 무무 @ <sub>®</sub>	
99	Time cotting Veer		
99	Time setting – Year	l 988	
		<u></u>	
		19	

### **Functional Setting**

There are three function keys on the display panel to implement special functions such as USB OTG, timer setting for output source priority and timer setting for charger source priority.

### 1. USB Function Setting

Insert an OTG USB disk into the USB port ( ). Press and hold " button for 3 seconds to enter USB Setup Mode. These functions including inverter firmware upgrade, data log export and internal parameters rewrite from the USB disk.

Procedure	LCD Screen
Step 1: Press and hold "button for 3 seconds to enter USB function setting mode.	LIDE A A
Step 2: Press " or " button to enter the selectable setting programs (detail descriptions in Step 3)	UPC ● ● LOG

**Step 3:** Please select setting program by following the procedure.

Program#	Operation Procedure	LCD Screen
∰/ <b>ひ</b> :	This function is to upgrade inverter firmware. If firmware upgrade is needed, pl	ease check with
Upgrade	your dealer or installer for detail instructions.	
firmware		
<del>]</del> ••:	This function is to over-write all parameter settings (TEXT file) with settings in	the On-The-Go
. —:	USB disk from a previous setup or to duplicate inverter settings. Please check	with your dealer
Re-write	or installer for detail instructions.	
internal		
parameters		
	By pressing "🗗" button to export data log from USB disk to the inverter. If	
	the selected function is ready, LCD will display "ー ぱ 』". Press " button to	[00 0 0
<del>]</del> \$.	confirm the selection again.	F83
Export data	Press "     button to select "Yes", LED 1 will flash once every second	
log	during the process. It will only display LOG and all LEDs will be on after this action is complete. Then, press " button to return to main screen.	YES NO
	Or press " button to select "No" to return to main screen.	

If no button is pressed for 1 minute, it will automatically return to main screen.

### **Error message for USB On-The-Go functions:**

Error Code	Messages
UO I	No USB disk is detected.
UO2	USB disk is protected from copying.
U03	Document inside the USB disk contains the wrong format.

If any error occurs, error code will only show for 3 seconds. After 3 seconds, it will automatically return to the main screen.

### 2. Timer Setting for Output Source Priority

This timer setting is to set up the output source priority per day.

The time is setting to to out up the output course, per day.	
Procedure	LCD Screen
<b>Step 1:</b> Press and hold "button for 3 seconds to enter Timer Setup Mode for output source priority.	USB @
	CIIL

Step 2: Press " or " button to enter the selectable programs (detail descriptions in Step 3).

**Step 3:** Please select setting program by following each procedure.

Program#	Operation Procedure	LCD Screen
∰/ <b>ບ</b>	Press "button to set up Utility First Timer. Press button to select staring time. Press button to adjust values and press button to confirm. Press button to select end time. Press "or "or "or button to adjust values, press button to confirm. The setting values are from 00 to 23, with 1-hour increment.	
<del>]</del> •••	Press "button to set up Solar First Timer. Press button to select staring time. Press "a" or "v" button to adjust values and press "d" to confirm. Press "button to select end time. Press "a" or "v" button to adjust values, press "d" button to confirm. The setting values are from 00 to 23, with 1-hour increment.	SUB ©
<del>]</del> -49	Press ""button to set up SBU Priority Timer. Press "button to select staring time. Press "or "v" button to adjust values and press "d" to confirm. Press "button to select end time. Press "or "v" button to adjust values, press "d" button to confirm. The setting values are from 00 to 23, with 1-hour increment.	SPN <b>©</b>

Press " button to exit the Setup Mode.

### 3. Timer Setting for the Charger Source Priority

This timer setting is to set up the charger source priority per day.

Procedure	LCD Screen
<b>Step 1:</b> Press and hold "button for 3 seconds to enter Timer Setup Mode for charging source priority.	CSO ♥
Step 2: Press " or " button to enter the selectable programs (detail	050
descriptions in Step 3).	

**Step 3:** Please select setting program by following each procedure.

Program#	Operation Procedure	LCD Screen
∰/₺	Press "button to set up Solar First Timer. Press button to select staring time. Press button to adjust values and press button to confirm. Press button to select end time. Press or or button to adjust values, press button to confirm. The setting values are from 00 to 23, with 1-hour increment.	
	Press "button to set up Solar & Utility Timer. Press "button to select staring time. Press " or " button to adjust values and press " to confirm. Press " button to select end time. Press " or " button to adjust values, press " button to confirm. The setting values are from 00 to 23, with 1-hour increment.	SM 8

<del>]</del> 49	Press "button to set up Solar Only Timer. Press "button to select staring time. Press "a" or "a" button to adjust values and press "d" to confirm. Press "button to select end time. Press "a" or "a" button to adjust values, press "d" button to confirm. The setting values are from 00 to 23, with 1-hour increment.	050 00 23	•
-----------------	--	-----------------	---

Press " button to exit the Setup Mode.

# **Display Setting**

The LCD display information will be switched in turn by pressing the "UP" or "DOWN" button. The selective information will be switched as per the following orders:

Selectable information	LCD display
	Input Voltage=230V, output voltage=230V
Input voltage/Output voltage (Default Display Screen)	INPUT EXCE  OUTPUT  WIPPT  MIPPT  MIPPT  MARGING  BATT
	Input frequency=50Hz
Input frequency	INPUT ASS  OUTPUT  OUTPUT  BATT
	PV voltage=260V
PV voltage	INPUT BY SYPASSS OUTPUT OUTPUT WEST STATEMENT OF STATEMEN
	PV current = 2.5A
PV current	OUTPUT  MPPT  CHARGING  BATT
	PV power = 500W
PV power	

AC and PV charging current=50A
LOAD
OUTPUT OUTPUT BATT
PV charging current=50A
OUTPUT  AC charging current=50A
LOAD
OUTPUT CHARGING BATT
AC and PV charging power=500W
OUTPUT  W  OUTPUT  V  MPPT  BATT  SCHARGING  BATT  LOAD  LOAD  LOAD
OUTPUT  W  OUTPUT  W  AC charging power=500W  LOAD
OUTPUT V CHARGING
Battery voltage=25.5V, output voltage=230V
OUTPUT V MPPT SCHARGING

	Output frequency=50Hz
Output frequency	OUTPUT COPP SCHARGING
Load percentage	Load percent=70%  LOAD  LOAD  OUTPUT  WAPPT
Load in VA	When connected load is lower than 1kVA, load in VA will present xxxVA like below chart.  LOAD  WA  WHEN CONTROL  WA  WITH THE TOTAL TOTAL  WA  WITH THE TOTAL  WA  WA  WA  WITH THE TOTAL  WA  WA  WA  WA  WA  WA  WA  WA  WA
Load in Watt	When load is lower than 1kW, load in W will present xxxW like below chart.  OUTPUT  W  MPPT  BATT  When load is larger than 1kW (≥1KW), load in W will present x.xkW like below chart.  LOAD  OUTPUT  W  MPPT  WPASS  OUTPUT  KW  MPPT  MPPT  MPPT  BATT  BATT  MPPT  M
Battery voltage/DC discharging current	Battery voltage=25.5V, discharging current=1A

Гoday
month
ear
ıt Total

	Main CPU version 00014.04.
Main CPU version checking.	EVPASS IN MPPT FCHARGING
	Secondary CPU version 00003.03.
Secondary CPU version checking.	LOAD BYPASSS
	MPPT FCHARGING
	Secondary Bluetooth version 00003.03.
Secondary Bluetooth version checking.	LOAD STRASS
	MPPT CHARGING BATT

# **Operating Mode Description**

Operation mode	Description	LCD display
Standby mode  Note:  *Standby mode: The inverter is not turned on yet but at this time, the inverter can charge battery without AC output.	No output is supplied by the unit but it still can charge batteries.	Charging by utility.  Charging by utility.  Charging by PV energy.  Charging by PV energy.  No charging.
Fault mode Note: *Fault mode: Errors are caused by inside circuit error or external reasons such as over temperature, output short circuited and so on.	PV energy and utility can charge batteries.	Charging by utility.  Charging by utility.  Charging by PV energy.  Charging by PV energy.  No charging.

The unit will provide output provide provide same line mode.  The unit will provide output power from the mains. It will also charge the battery at line mode.	splay
If eith as ou	BYPASS  TO SCHARGING  TO SCHAR
provide the provid	

Operation mode	Description	LCD display
Battery Mode	The unit will provide output power from battery and/or PV power.	Power from battery and PV energy.  PV energy will supply power to the loads and charge battery at the same time. No utility is available.  Power from battery only.  Power from PV energy only.

# **Battery Equalization Description**

Battery equalization function is built into the charge controller. It reverses the buildup of negative chemical effects such as stratification, a condition where acid concentration is greater at the bottom of the battery than at the top. Equalization also helps to remove sulfate crystals that may have built up on the plates. If left unchecked, this condition, called sulfation, will reduce the overall capacity of the battery. Therefore, it's recommended to equalize the battery periodically.


#### How to Activate Equalization Function

You must enable battery equalization function in LCD setting Program 30 first. You can then apply this function by either one of the following methods:

- 1. Setting equalization interval in Program 35.
- 2. Activate equalization immediately in Program 36.


#### When to Equalize

In floating charge stage, when setting the equalization interval (battery equalization cycle) is reached, or equalization is activated immediately, the controller will start to enter Equalize Mode.




## Equalize Charging and Timeout

In Equalize Mode, the controller will supply power to charge battery as much as possible until battery voltage reach the equalization voltage. Then, constant-voltage regulation is applied to maintain battery voltage at the equalization level. The battery will remain in the Equalize Mode until the equalization timer runs out.



However, in Equalize Mode, if the battery equalization timer runs out and the battery voltage doesn't recover to the battery equalization voltage point, the charge controller will extend the battery equalized time until battery voltage achieves equalization voltage. If the battery voltage is still lower than equalization voltage when the extension runs out, the charge controller will stop equalization and return to the floating charging stage.



# **Fault Reference Code**

Fault Code	Fault Event	Icon on
01	Fan is locked when inverter is off.	F0
02	Over temperature	503
03	Battery voltage is too high	F03
04	Battery voltage is too low	F03
05	Output short circuited or over temperature is detected by internal converter components.	FÖS
06	Output voltage is too high.	F86
07	Overload time out	607
08	Bus voltage is too high	F08
09	Bus soft start failed	F09
51	Over current or surge	FS
52	Bus voltage is too low	552
53	Inverter soft start failed	893
55	Over DC voltage in AC output	855
57	Current sensor failed	FS7
58	Output voltage is too low	F58
59	PV voltage is over limitation	F59

# **Warning Indicator**

Warning Code	Warning Event	Audible Alarm	Icon flashing
01	Fan is locked when inverter is on.	Beep three times every second	
02	Over temperature	None	02 <b>®</b>
03	Battery is over-charged	Beep once every second	
04	Low battery	Beep once every second	<pre>[] \\∞</pre>
07	Overload	Beep once every 0.5 second	
10	Output power derating	Beep twice every 3 seconds	
15	PV energy is low.	Beep twice every 3 seconds	Ūį
16	High AC input (>280VAC) during BUS soft start	None	164
32	Communication failure between inverter and remote display panel	None	
E9	Battery equalization	None	
6P	Battery is not connected	None	6P@

# **SPECIFICATIONS**

Table 1 Line Mode Specifications

INVERTER MODEL	1.5KW 3KW 5KW		5KW
Input Voltage Waveform	Sinusoidal (utility or generator)		
Nominal Input Voltage	230Vac		
Low Loss Voltage	170Vac±7V (UPS); 90Vac±7V (Appliances)		
Low Loss Return Voltage	180Vac±7V (UPS); 100Vac±7V (Appliances)		
High Loss Voltage		280Vac±7V	
High Loss Return Voltage		270Vac±7V	
Max AC Input Voltage		300Vac	
Nominal Input Frequency	50H	z / 60Hz (Auto detection)	)
Low Loss Frequency	40±1Hz		
Low Loss Return Frequency	42±1Hz		
High Loss Frequency	65±1Hz		
High Loss Return Frequency	63±1Hz		
Output Short Circuit Protection	Circuit Breaker		
Efficiency (Line Mode)	>95% ( Rated R load, battery full charged )		
Transfer Time	10ms typical (UPS); 20ms typical (Appliances)		
Output power derating: When AC input voltage drops to 170V, the output power will be derated.	Output Power  Rated Power  50% Power  90V 170V 280V Input Voltage		V Input Voltage

Table 2 Inverter Mode Specifications

INVERTER MODEL	1.5KW 3KW 5KW		
Rated Output Power	1.5KVA/1.5KW	3KVA/3KW	5KVA/5KW
Output Voltage Waveform	,	Pure Sine Wave	
Output Voltage Regulation		230Vac±5%	
Output Frequency		50Hz	
Peak Efficiency		93%	
Overload Protection	5s@≥130	0% load; 10s@105%	~130% load
Surge Capacity	2* rated power for 5 seconds		
Nominal DC Input Voltage	24	Vdc	48Vdc
Cold Start Voltage	23.0Vdc 46.0Vdc		
Low DC Warning Voltage			
@ load < 50%	23.0Vdc		46.0Vdc
@ load ≥ 50%	22.0Vdc 44.0Vdc		
Low DC Warning Return Voltage			
@ load < 50%	23.5\	<b>/</b> dc	47.0Vdc
@ load ≥ 50%	23.0\	Vdc	46.0Vdc
Low DC Cut-off Voltage			
@ load < 50%	21.5Vdc		43.0Vdc
@ load ≥ 50%	21.0Vdc 42.0Vdc		42.0Vdc
High DC Recovery Voltage	32Vdc 62Vdc		
High DC Cut-off Voltage	33Vdc 63Vdc		
No Load Power Consumption	<35W <50W		

Table 3 Charge Mode Specifications

and a committee of comments					
<b>Utility Chargin</b>	Utility Charging Mode				
INVERTER MODEL		1.5KW	зкพ	5KW	
Charging Algorithm			3-Step		
AC Charging Current (Max)		40Amp 60Amp ( $@V_{I/P}=230Vac$ ) ( $@V_{I/P}=230Vac$ )		•	
<b>Bulk Charging</b>	Flooded Battery	2	29.2	58.4	
Voltage	AGM / Gel Battery	2	28.2	56.4	
Floating Charg	ing Voltage	27	7Vdc	54Vdc	
Charging Curve		2.250vic  TO TI  T1 = 10* TO, minimum 10mins, maximum Bins  Current  Bulk (Constant Current) (Constant Voltage) (Floating)		Current Time	
MPPT Solar Cha					
INVERTER MOD		1.5KW	3KW	5KW	
Max. PV Array		2000W	4000W	5000W	
Nominal PV Vol		240Vdc		320Vdc	
Start-up Voltag	je	150Vdc +/- 10Vdc			
PV Array MPPT	Voltage Range	120~380Vdc 120~450Vdc		450Vdc	
Max. PV Array	Open Circuit Voltage	<b>e</b> 400Vdc 500Vdc		OVdc	
Max Charging ( (AC charger plu	Current us solar charger)	60A 80Amp		Amp	

**Table 4 General Specifications** 

INVERTER MODEL	1.5KW	3KW	5KW
Operating Temperature Range	-10°C to 50°C		
Storage temperature	-15°C~ 60°C		
Humidity	5% to 95% Relative Humidity (Non-condensing)		
Dimension (D*W*H), mm	100 x 280 x 390 115 x 300 x 400		
Net Weight, kg	8.5	9	10

# **TROUBLE SHOOTING**

Problem	LCD/LED/Buzzer	Explanation / Possible cause	What to do
Unit shuts down automatically during startup process.	LCD/LEDs and buzzer will be active for 3 seconds and then complete off.	The battery voltage is too low (<1.91V/Cell)	Re-charge battery.     Replace battery.
No response after power on.	No indication.	The battery voltage is far too low. (<1.4V/Cell)     Internal fuse tripped.	<ol> <li>Contact repair center for replacing the fuse.</li> <li>Re-charge battery.</li> <li>Replace battery.</li> </ol>
	Input voltage is displayed as 0 on the LCD and green LED is flashing.	Input protector is tripped	Check if AC breaker is tripped and AC wiring is connected well.
Mains exist but the unit works in battery mode.	Green LED is flashing.	Insufficient quality of AC power. (Shore or Generator)	<ol> <li>Check if AC wires are too thin and/or too long.</li> <li>Check if generator (if applied) is working well or if input voltage range setting is correct. (UPS→Appliance)</li> </ol>
	Green LED is flashing.	Set "SUB" (solar first) as the priority of output source.	Change output source priority to "USB" (utility first).
When the unit is turned on, internal relay is switched on and off repeatedly.	LCD display and LEDs are flashing	Battery is disconnected.	Check if battery wires are connected well.
		Overload error. The inverter is overload 110% and time is up.	Reduce the connected load by switching off some equipment.
	Fault code 07	If PV input voltage is higher than specification, the output power will be derated. At this time, if connected loads is higher than derated output power, it will cause overload.	Reduce the number of PV modules in series or the connected load.
	Fault code 05	Output short circuited.	Check if wiring is connected well and remove abnormal load.
	Fault code 02	Temperature of internal converter component is over 120°C.  Internal temperature of inverter	Check whether the air flow of the unit is blocked or whether the ambient temperature is too high.
Buzzer beeps continuously and		component is over 100°C.  Battery is over-charged.	Return to repair center.
red LED is on.	Fault code 03	The battery voltage is too high.	Check if spec and quantity of batteries are meet requirements.
	Fault code 01	Fan fault	Replace the fan.
	Fault code 06/58	Output abnormal (Inverter voltage below than 190Vac or is higher than 260Vac)	Reduce the connected load.     Return to repair center
	Fault code 08/09/53/57	Internal components failed.	Return to repair center.
	Fault code 51	Over current or surge.	Restart the unit, if the error
	Fault code 52	Bus voltage is too low.	happens again, please return
	Fault code 55	Output voltage is unbalanced.	to repair center.
	Fault code 59	PV input voltage is beyond the specification.	Reduce the number of PV modules in series.

# **Appendix A: Approximate Back-up Time Table**

Model	Load (VA)	Backup Time @ 24Vdc 100Ah (min)	Backup Time @ 24Vdc 200Ah (min)
	150	908	2224
	300	449	1100
	450	338	815
	600	222	525
1.5KW	750	177	414
1.5KW	900	124	303
	1050	110	269
	1200	95	227
	1350	82	198
	1500	68	164

Model	Load (VA)	Backup Time @ 24Vdc 100Ah (min)	Backup Time @ 24Vdc 200Ah (min)
	300	449	1100
	600	222	525
	900	124	303
	1200	95	227
3KW	1500	68	164
SKVV	1800	56	126
	2100	48	108
	2400	35	94
	2700	31	74
	3000	28	67

Model	Load (VA)	Backup Time @ 48Vdc 100Ah (min)	Backup Time @ 48Vdc 200Ah (min)
5KW	500	613	1288
	1000	268	613
	1500	158	402
	2000	111	271
	2500	90	215
	3000	76	182
	3500	65	141
	4000	50	112
	4500	44	100
	5000	40	90

**Note:** Backup time depends on the quality of the battery, age of battery and type of battery. Specifications of batteries may vary depending on different manufacturers.

# **Appendix B: BMS Communication Installation**

#### 1. Introduction


If connecting to lithium battery, it is recommended to purchase a custom-made RJ45 communication cable. Please check with your dealer or integrator for details.

This custom-made RJ45 communication cable delivers information and signal between lithium battery and the inverter. These information are listed below:

- Re-configure charging voltage, charging current and battery discharge cut-off voltage according to the lithium battery parameters.
- Have the inverter start or stop charging according to the status of lithium battery.


## 2. Pin Assignment for BMS Communication Port

	Definition
PIN 1	RS232TX
PIN 2	RS232RX
PIN 3	RS485B
PIN 4	NC
PIN 5	RS485A
PIN 6	CANH
PIN 7	CANL
PIN 8	GND



#### 3. AOESS48-LFP4100

# **Lithium Battery Communication Configuration**




① Dial switch address: Used to set the address bit of battery module when multiple batteries are wired in parallel.

No.	Dial switch address					DC/OF	CAN	
	#1	#2	#3	#4	#5	#6	RS485	CAN
0	OFF	OFF	OFF	OFF	OFF	OFF	Pack 0	Invalid
1	ON	OFF	OFF	OFF	OFF	OFF	Pack 1	Master
2	OFF	ON	OFF	OFF	OFF	OFF	Pack 2	Slave
3	ON	ON	OFF	OFF	OFF	OFF	Pack 3	Slave
4	OFF	OFF	ON	OFF	OFF	OFF	Pack 4	Slave
5	ON	OFF	ON	OFF	OFF	OFF	Pack 5	Slave
6	OFF	ON	ON	OFF	OFF	OFF	Pack 6	Slave
7	ON	ON	ON	OFF	OFF	OFF	Pack 7	Slave
8	OFF	OFF	OFF	ON	OFF	OFF	Pack 8	Slave
9	ON	OFF	OFF	ON	OFF	OFF	Pack 9	Slave


Note: The BMS of master pack does not support to connect the inverter and the host computer at the same time, otherwise it will occur the communication errors.

## **Installation and Operation**

After configuration, please install LCD panel with inverter and Lithium battery with the following steps. Step 1. Use special RJ45 cable (P/N: SPC-COMM) to connect inverter and Lithium battery in the RS485 port.



Step 2. Switch on Lithium battery by pressing the reset button.



Step 3. Turn on the inverter.



Step 4. Be sure to select battery type as "Lib" in LCD program 5.






If communication between the inverter and battery is successful, the battery icon on LCD display will flash. Generally speaking, it will take longer than 1 minute to establish communication.


# 4. LIO-4810-150A/ESS LIO-I 4810

# **Lithium Battery Communication Configuration**

## LIO-4805/LIO-4810-150A



#### **® ESS LIO-I 4810**




ID Switch indicates the unique ID code for each battery module. It's required to assign an identical ID to each battery module for normal operation. We can set up the ID code for each battery module by rotating the PIN number on the ID switch. From number 0 to 9, the number can be random; no particular order. Maximum 10 battery modules can be operated in parallel.


## **Installation and Operation**

After ID no. is assigned for each battery module, please set up LCD panel in inverter and install the wiring connection as following steps.

Step 1: Use supplied RJ11 signal cable to connect into the extension port ( P1 or P2 ).



Step 2: Use supplied RJ45 cable (from battery module package) to connect inverter and Lithium battery.



Step 3: Turn the breaker switch "ON". Now, the battery module is ready for DC output.



Step 4: Press Power on/off button on battery module for 5 secs, the battery module will start up. \*If the manual button cannot be approached, just simply turn on the inverter module. The battery module will be automatically turned on.

Step 5. Turn on the inverter.



Step 6. Be sure to select battery type as "LIB" in LCD program 5.




416

If communication between the inverter and battery is successful, the battery icon on LCD display will flash. Generally speaking, it will take longer than 1 minute to establish communication.

#### PYLONTECH

## **Lithium Battery Communication Configuration**



①Dip Switch: There are 4 Dip Switches that sets different baud rate and battery group address. If switch position is turned to the "OFF" position, it means "0". If switch position is turned to the "ON" position, it means "1".

Dip 1 is "ON" to represent the baud rate 9600.

Dip 2, 3 and 4 are reserved for battery group address.

Dip switch 2, 3 and 4 on master battery (first battery) are to set up or change the group address.

Dip switch 2, 3 and 4 on master battery (first battery) are to set up or change the group address.


**NOTE:** "1" is upper position and "0" is bottom position.

Dip 1	Dip 2	Dip 3	Dip 4	Group address
	0	0	0	Single group only. It's required to set up master battery with this setting and slave batteries are unrestricted.
	1	0	0	Multiple group condition. It's required to set up master battery on the first group with this setting and slave batteries are unrestricted.
1: RS485 baud rate=9600	0	1	0	Multiple group condition. It's required to set up master battery on the second group with this setting and slave batteries are unrestricted.
Restart to take	1	1	0	Multiple group condition. It's required to set up master battery on the third group with this setting and slave batteries are unrestricted.
effect	0	0	1	Multiple group condition. It's required to set up master battery on the fourth group with this setting and slave batteries are unrestricted.
	1	0	1	Multiple group condition. It's required to set up master battery on the fifth group with this setting and slave batteries are unrestricted.


**NOTE:** The maximum groups of lithium battery is 5 and for maximum number for each group, please check with battery manufacturer.

### **Installation and Operation**


After configuration, please install LCD panel with inverter and Lithium battery with the following steps. Step 1. Use custom-made RJ45 cable to connect inverter and Lithium battery.



Step 2. Switch on Lithium battery.



Step 3. Press more than three seconds to start Lithium battery. Output power is ready.



Step 4. Turn on the inverter.



Step 5. Be sure to select battery type as "PYL" in LCD program 5.



# PYL


If communication between the inverter and battery is successful, the battery icon on LCD display will flash. Generally speaking, it will take longer than 1 minute to establish communication.

#### **Active Function**


This function is to activate lithium battery automatically while commissioning. After battery wiring and commissioning are complete, if battery is not detected, the inverter will automatically activate battery when powered on.

#### 6. WECO

Step 1. Use a custom-made RJ45 cable to connect inverter and Lithium battery.



Step 2. Switch on Lithium battery.



Step 3. Turn on the inverter.



Step 4. Be sure to select battery type as "WEC" in LCD program 5.



υEC


If communication between the inverter and battery is successful, the battery icon will "flash". Usually, it will take longer than 1 minute to establish communication.



on LCD display

#### 7. SOLTARO

Step 1. Use a custom-made RJ45 cable to connect inverter and Lithium battery.



Step 2. Open DC isolator and switch on Lithium battery.



Step 3. Turn on the inverter.



Step 4. Be sure to select battery type as "SOL" in LCD program 5.



SOL


If communication between the inverter and battery is successful, the battery icon will "flash". Usually, it will take longer than 1 minute to establish communication.



on LCD display

## **LCD Display Information**

Press "▲" or " ¥ button to switch LCD display information. It will show battery pack and battery group number before "Main CPU version checking" as shown below.



#### **Code Reference**

Related information code will be displayed on LCD screen. Please check inverter LCD screen for the operation.

Code	Descriptio n	Action
60 <b></b>	If battery status is not allowed to charge and discharge after the communication between the inverter and battery is successful, it will show code 60 to stop charging and discharging battery.	
5 lø	Communication lost (only available when the battery type is setting as "Pylontech Battery".)  After battery is connected, communication signal is not detected for 3 minutes, buzzer will beep. After 10 minutes, inverter will stop charging and discharging to lithium battery.  Communication lost occurs after the inverter and battery is connected successfully, buzzer beeps immediately.	
59 <b>&amp;</b>	If battery status is not allowed to charge after the communication between the inverter and battery is successful, it will show code 69 to stop charging battery.	
70	If battery status must to be charged after the communication between the inverter and battery is successful, it will show code 70 to charge battery.	
]   <u>@</u>	If battery status is not allowed to discharge after the communication between the inverter and battery is successful, it will show code 71 to stop discharging battery.	

Africa

Spain